



## ECO Chlorophyll Fluorometer Characterization Sheet

Date: 4/24/2019

S/N: BBFL2W-1418

Chlorophyll concentration expressed in µg/l can be derived using the equation:

$$\text{CHL (}\mu\text{g/l)} = \text{Scale Factor} * (\text{Output} - \text{Dark counts})$$

	<b>Digital</b>
<b>Dark counts</b>	50 counts
<b>Scale Factor (SF)</b>	0.0183 µg/l/count
<b>Maximum Output</b>	4130 counts
<b>Resolution</b>	1.3 counts
<b>Ambient temperature during characterization</b>	22.0 °C

**Dark Counts:** Signal output of the meter in clean water with black tape over detector.

**SF:** Determined using the following equation:  $SF = x \div (\text{output} - \text{dark counts})$ , where x is the concentration of the solution used during instrument characterization. SF is used to derive instrument output concentration from the raw signal output of the fluorometer.

**Maximum Output:** Maximum signal output the fluorometer is capable of.

**Resolution:** Standard deviation of 1 minute of collected data.

The relationship between fluorescence and chlorophyll-a concentrations in-situ is highly variable. The scale factor listed on this document was determined using a mono-culture of phytoplankton (*Thalassiosira weissflogii*). The population was assumed to be reasonably healthy and the concentration was determined by using the absorption method. To accurately determine chlorophyll concentration using a fluorometer, you must perform secondary measurements on the populations of interest. This is typically done using extraction-based measurement techniques on discrete samples. For additional information on determining chlorophyll concentration see "Standard Methods for the Examination of Water and Wastewater" part 10200 H, published jointly by the American Public Health Association, American Water Works Association, and the Water Environment Federation.

## ECO CDOM Fluorometer Characterization Sheet

Date: 4/24/2019

S/N: BBFL2W-1418

---

CDOM concentration expressed in ppb can be derived using the equation:

$$\text{CDOM (ppb)} = \text{Scale Factor} * (\text{Output} - \text{Dark Counts})$$

<b>Dark Counts</b>	<b>Digital</b>
<b>Scale Factor (SF)</b>	46 counts
<b>Maximum Output</b>	0.0785 ppb/count
<b>Resolution</b>	4130 counts
	1.0 counts
Ambient temperature during characterization	22.0 °C

---

**Dark Counts:** Signal output of the meter in clean water with black tape over detector.

**SF:** Determined using the following equation:  $SF = x \div (\text{output} - \text{dark counts})$ , where  $x$  is the concentration of the solution used during instrument characterization. SF is used to derive instrument output concentration from the raw signal output of the fluorometer.

**Maximum Output:** Maximum signal output the fluorometer is capable of.

**Resolution:** Standard deviation of 1 minute of collected data.

# NTU Characterization Sheet

Date: 4/24/2019

S/N: BBFL2W-1418

## Nephelometric Turbidity Unit (NTU) Scale Factor

Turbidity units expressed in NTU can be derived using the equation:

$$\text{NTU} = \text{Scale Factor} \times (\text{Output} - \text{Dark Counts})$$

			<b>Digital</b>
<b>Dark Counts</b>		50	counts
<b>NTU Solution Value</b>		2613	counts
<b>Scale Factor (SF)</b>		0.0499	NTU/count
<b>Maximum Output</b>		4130	counts
<b>Resolution</b>		1.0	counts
Ambient temperature during calibration	22	°C	

**Dark Counts:** Signal output of the meter in clean water with black tape over detector.

**SF:** Scale factor is determined using the following equation:  $\text{SF} = \text{xx} \div (\text{Output} - \text{Dark Counts})$ , where xx is the value of a Formazin concentration. For example:  $12.2 \div (2011 - 50) = 0.0062$ .

**Maximum Output:** Maximum signal output the meter is capable of.

**Resolution:** standard deviation of 1 minute of collected data.