

Layout No:
Circuit Diagram No:
Program Version: 3, Build: 24

Product: Oxygen Optode 3835
Serial No: 1879

1. Visual and Mechanical Checks:

- 1.1. O-ring surface
- 1.2. Soldering quality
- 1.3. Visual surface
- 1.4. Galvanic isolation between housing and electronics

2. Current Drain and Voltages:

- 2.1. Average current drain at 0.5Hz sampling (Max: 38mA) 31.5 mA
- 2.2. Current drain in sleep (Max: 300µA) 212 µA
- 2.3. Quiescent current drain from -9V (Max: 5µA) µA
- 2.4. DSP voltage, IC5.1 ($3.3 \pm 0.15V$) 3.29 V
- 2.5. Excitation driver voltage, IC1.1 ($3.3 \pm 0.15V$) 3.32 V
- 2.6. Flash/RS232 driver voltage, IC7.4 ($5 \pm 0.2V$) 5.07 V

3. Receiver test:

- 3.1. Average of Receiver readings ($0 \pm 50mV$) -11 mV
- 3.2. Standard Deviation of Receiver readings (Max: 10mV) 1.74 mV

4. Performance Test in Air, 0°C Temperature:

- 4.1. Amplitude measurement (Blue: 220 – 470mV) 374.94 mV
- 4.2. Phase measurement (Blue: 30 ± 5) 36.1°
- 4.3. Standard deviation of Phase measurement: (Max: 0.02°) 0.025°
- 4.4. Temperature measurement: ($700 \pm 300mV$) 678.16 mV
- 4.5. SR10 Output tested (Set_Output(-100))

5. Performance Test in Air, 20°C Temperature:

- 5.1. Amplitude measurement (Blue: 290 – 470mV) 376.4 mV
- 5.2. Phase measurement (Blue: $25 \pm 5^\circ$) 30.9°
- 5.3. Standard deviation of Phase measurement: (Max: 0.02°) 0.010°
- 5.4. Temperature measurement: ($100 \pm 300mV$) -91.09 mV
- 5.5. SR10 Output tested (Set_Output(-100))

6. Performance Test in Air, 40°C Temperature:

- 6.1. Amplitude measurement (Blue: 320 – 500mV) 376.47 mV
- 6.2. Phase measurement (Blue: $22 \pm 5^\circ$) 28.0°
- 6.3. Standard deviation of Phase measurement: (Max: 0.02°) 0.005°
- 6.4. Temperature measurement: ($-500 \pm 300mV$) -533.9 mV
- 6.5. SR10 Output tested (Set_Output(-100))

Date: 10 Jun 2014

Sign:


Lene Magnussen, Production Engineer

Sensing Foil Batch No: 1023
Certificate No:

Product: Oxygen Optode 3835
Serial No: 1879
Calibration Date: 07 Jun 2014

This is to certify that this product has been calibrated using the following instruments:

Calibration Bath model FNT 321-1-40
 ASL Digital Thermometer model F250 Serial: 6792/06

Parameter: Internal Temperature:

Calibration points and readings:

Temperature (°C)	0.94	11.90	23.86	35.88
Reading (mV)	698.03	344.85	-53.00	-421.72

Giving these coefficients

Index	0	1	2	3
TempCoef	2.22350E01	-3.04308E-02	2.80463E-06	-4.17194E-09

Parameter: Oxygen:

	O2 Concentration	Air Saturation
Range:	0-500 µM ¹⁾	0 - 120%
Accuracy ¹⁾ :	< ±8µM or ±5% (whichever is greater)	±5%
Resolution:	< 1 µM	< 0.4%
Settling Time (63%):	< 25 seconds	

Calibration points and readings²⁾:

	Air Saturated Water	Zero Solution (Na ₂ SO ₃)
Phase reading (°)	3.46944E+01	6.71527E+01
Temperature reading (°C)	9.91297E+00	2.12299E+01
Air Pressure (hPa)	9.78957E+02	

Giving these coefficients

Index	0	1	2	3
PhaseCoef	-6.44396E00	1.16885E00	0.00000E00	0.00000E00

¹⁾ Valid for 0 to 2000m (6562ft) depth, salinity 33 - 37ppt

²⁾ The calibration is performed in fresh water and the salinity setting is set to: 0

Sensing Foil Batch No: 1023
Certificate No:**Product:** Oxygen Optode 3835
Serial No: 1879
Calibration Date: 07 Jun 2014

SR10 Scaling Coefficients:

At the SR10 output the Oxygen Optode 3830 can give either absolute oxygen concentration in μM or air saturation in %. The setting of the internal property "Output" ³⁾, controls the selection of the unit. The coefficients for converting SR10 raw data to engineering units are fixed.

Output = -1	Output = -2
A = 0	A = 0
B = 4.883E-01	B = 1.465E-01
C = 0	C = 0
D = 0	D = 0
Oxygen (μM) = A + BN + CN2 + DN3	Oxygen (%) = A + BN + CN2 + DN3

³⁾ The default output setting is set to -1

Date: 10 Jun 2014

Sign:



Tor-Ove Kvalvaag, Calibration Engineer

AANDERAA DATA INSTRUMENTS AS

Layout No:
Circuit Diagram No:
Program Version: 3, Build: 24

Product: Oxygen Optode 3835
Serial No: 1884

1. Visual and Mechanical Checks:

- 1.1. O-ring surface
- 1.2. Soldering quality
- 1.3. Visual surface
- 1.4. Galvanic isolation between housing and electronics

2. Current Drain and Voltages:

- | | |
|--|---------|
| 2.1. Average current drain at 0.5Hz sampling (Max: 38mA) | 31.8 mA |
| 2.2. Current drain in sleep (Max: 300µA) | 215 µA |
| 2.3. Quiescent current drain from -9V (Max: 5µA) | µA |
| 2.4. DSP voltage, IC5.1 (3.3 ±0.15V) | 3.31 V |
| 2.5. Excitation driver voltage, IC1.1 (3.3 ±0.15V) | 3.32 V |
| 2.6. Flash/RS232 driver voltage, IC7.4 (5 ±0.2V) | 5.08 V |

3. Receiver test:

- | | |
|--|---------|
| 3.1. Average of Receiver readings (0 ±50mV) | -8 mV |
| 3.2. Standard Deviation of Receiver readings (Max: 10mV) | 2.04 mV |

4. Performance Test in Air, 0°C Temperature:

- | | |
|--|-----------|
| 4.1. Amplitude measurement (Blue: 220 – 470mV) | 371.4 mV |
| 4.2. Phase measurement (Blue: 30 ±5) | 36.5 ° |
| 4.3. Standard deviation of Phase measurement: (Max: 0.02°) | 0.032 ° |
| 4.4. Temperature measurement: (700 ±300mV) | 697.33 mV |
| 4.5. SR10 Output tested (Set_Output(-100)) | |

5. Performance Test in Air, 20°C Temperature:

- | | |
|--|-----------|
| 5.1. Amplitude measurement (Blue: 290 – 470mV) | 373.59 mV |
| 5.2. Phase measurement (Blue: 25 ±5°) | 31.3 ° |
| 5.3. Standard deviation of Phase measurement: (Max: 0.02°) | 0.027 ° |
| 5.4. Temperature measurement: (100 ±300mV) | -31.18 mV |
| 5.5. SR10 Output tested (Set_Output(-100)) | |

6. Performance Test in Air, 40°C Temperature:

- | | |
|--|------------|
| 6.1. Amplitude measurement (Blue: 320 – 500mV) | 365 mV |
| 6.2. Phase measurement (Blue: 22 ±5°) | 28.3 ° |
| 6.3. Standard deviation of Phase measurement: (Max: 0.02°) | 0.014 ° |
| 6.4. Temperature measurement: (-500 ±300mV) | -489.81 mV |
| 6.5. SR10 Output tested (Set_Output(-100)) | |

Date: 10 Jun 2014

Sign:


Lene Magnussen, Production Engineer

Sensing Foil Batch No: 1023
Certificate No:

Product: Oxygen Optode 3835
Serial No: 1884
Calibration Date: 07 Jun 2014

This is to certify that this product has been calibrated using the following instruments:

Calibration Bath model FNT 321-1-40
 ASL Digital Thermometer model F250 Serial: 6792/06

Parameter: Internal Temperature:

Calibration points and readings:

Temperature (°C)	0.94	11.90	23.86	35.88
Reading (mV)	732.48	386.93	-6.43	-375.72

Giving these coefficients

Index	0	1	2	3
TempCoef	2.36580E01	-3.08591E-02	2.86692E-06	-4.20179E-09

Parameter: Oxygen:

	O2 Concentration	Air Saturation
Range:	0-500 µM ¹⁾	0 - 120%
Accuracy ¹⁾ :	< ±8µM or ±5% (whichever is greater)	±5%
Resolution:	< 1 µM	< 0.4%
Settling Time (63%):	< 25 seconds	

Calibration points and readings²⁾:

	Air Saturated Water	Zero Solution (Na ₂ SO ₃)
Phase reading (°)	3.50380E+01	6.73434E+01
Temperature reading (°C)	9.91021E+00	2.12458E+01
Air Pressure (hPa)	9.78957E+02	

Giving these coefficients

Index	0	1	2	3
PhaseCoef	-7.03471E00	1.17424E00	0.00000E00	0.00000E00

¹⁾ Valid for 0 to 2000m (6562ft) depth, salinity 33 - 37ppt

²⁾ The calibration is performed in fresh water and the salinity setting is set to: 0

Sensing Foil Batch No: 1023
Certificate No:**Product:** Oxygen Optode 3835
Serial No: 1884
Calibration Date: 07 Jun 2014

SR10 Scaling Coefficients:

At the SR10 output the Oxygen Optode 3830 can give either absolute oxygen concentration in μM or air saturation in %. The setting of the internal property "Output" ³⁾, controls the selection of the unit. The coefficients for converting SR10 raw data to engineering units are fixed.

Output = -1	Output = -2
A = 0	A = 0
B = 4.883E-01	B = 1.465E-01
C = 0	C = 0
D = 0	D = 0
Oxygen (μM) = A + BN + CN2 + DN3	Oxygen (%) = A + BN + CN2 + DN3

³⁾ The default output setting is set to -1

Date: 10 Jun 2014

Sign:



Tor-Ove Kvalvaag, Calibration Engineer

AANDERAA DATA INSTRUMENTS AS

Certificate No: 3853_1023_40408
Batch No: 1023

Product: O2 Sensing Foil PSt3 3853
Calibration Date: 18 Aug 2010

Calibration points and phase readings (degrees)

Temperature (°C)		3.81	10.40	19.94	29.39	38.67
Pressure (hPa)		970.25	970.25	970.25	970.25	970.25
O2 in % of O2+N2	0.00	72.97	72.50	71.81	71.02	70.09
	1.00	68.13	67.16	65.72	64.27	62.70
	2.00	64.72	63.48	61.63	59.79	57.95
	5.00	56.48	54.75	52.40	50.16	48.05
	10.00	47.08	45.17	42.67	40.36	38.33
	20.90	35.87	34.01	31.74	29.73	28.04
	30.00	30.48	28.83	26.79	25.03	23.56

Giving these coefficients ¹⁾

Index	0	1	2	3
C0 Coefficient	4.27019E+03	-1.32724E+02	2.15630E+00	-1.40276E-02
C1 Coefficient	-2.29730E+02	5.74242E+00	-6.85358E-02	1.88612E-04
C2 Coefficient	5.06402E+00	-9.62085E-02	5.22181E-04	7.70890E-06
C3 Coefficient	-5.26332E-02	7.15467E-04	3.31185E-06	-1.86124E-07
C4 Coefficient	2.10917E-04	-1.84088E-06	-4.28646E-08	1.11120E-09

¹⁾ Ask for Form No 621S when this O2 Sensing Foil is used in Oxygen Sensor 3830 with Serial Numbers lower than 184.

Date: 6/27/2014

Sign:



Tor-Ove Kvalvaag, Calibration Engineer

AANDERAA DATA INSTRUMENTS AS