

Biospherical Instruments Inc

CALIBRATION CERTIFICATE

UNDERWATER PAR SENSOR WITH LOG AMPLIFIER

Calibration Date: 06/01/16

Job No.: R12593

Model Number: QSP200L4S

Serial Number: 4603

Operator: TPC

Standard Lamp: V-035(3/4/15)

Operating Voltage Range: 6 to 15 VDC (+)

Note: The QSP200L4S uses a log amplifier to measure the detector signal current with $V = \log I$ (Amps) / I_{Ref}
To calculate irradiance, use this formula:

$$\text{Irradiance} = \text{Calibration factor} * (10^{\text{Light Signal Voltage}} - 10^{\text{Dark Voltage}})$$

With the appropriate (solar corrected) Irradiance Calibration Factor:

Dry Calibration Factor:	1.30E+13	quanta/cm ² ·sec per volt	2.16E-05	μEinsteins/cm ² ·sec per volt
Wet Calibration Factor:	2.29E+13	quanta/cm ² ·sec per volt	3.81E-05	μEinsteins/cm ² ·sec per volt

Sensor Test Data and Results⁴⁾

Sensor Supply Current (Dark):		67.8	mA							
Supply Voltage:		6	Volts							
Lamp Integrated PAR Irradiance:		1.03E+16	quanta/cm ² ·sec	0.01713	μEinsteins/cm ² sec					
SC3 Immersion Coefficient:		0.5664	Scalar Correction:	1	PAR Solar Correction:					1.0000
Nominal Filter OD	Calibrated Trans.	Sensor Voltage	Measured Trans.	Measured Signal (Amps)	Estimated Signal (Amps)	Calc. Output (Volts)	Error (Volts)	Error (%)	Test Irrad. (quanta/cm ² ·sec)	
No Filter	100.00%	2.901	100.00%	7.96E-08	7.96E-08	2.902	0.001	0.0	1.03E+16	
0.3	36.10%	2.461	36.19%	2.88E-08	2.87E-08	2.461	0.000	-0.3	3.73E+15	
0.5	27.60%	2.346	27.73%	2.21E-08	2.20E-08	2.345	-0.001	-0.5	2.86E+15	
1	9.27%	1.875	9.25%	7.37E-09	7.38E-09	1.877	0.002	0.2	9.55E+14	
2	1.11%	1.003	1.08%	8.62E-10	8.84E-10	1.013	0.010	2.5	1.12E+14	
3	0.05%	0.306	0.07%	5.61E-11	4.25E-11	0.276	-0.030	-24.3	7.27E+12	

Dark Before: 0.165 Volts

Light - No Filter Hldr.: 2.901 Volts

Dark After - NFH: 0.165 Volts

Average Dark: 0.165 Volts

$I_{Ref} = 1.00E-10$ Amps

$I_{Dark} = 1.46E-10$ Amps

$10^{V_{Dark}} = 1.462766$

RG780

0.234

Notes:

1. Annual calibration is recommended.
2. The collector should be cleaned frequently with alcohol.
- 4) This section is for internal use and for more advanced analysis.